

**Location Properties**

Location Name = CC1

Location ID = xxx

**Report Properties**

Start Time = 2021-06-03 13:06:00

Time Offset = -04:00:00

Duration = 00:00:00

Readings = 0

**Instrument Properties**

Device Model = Aqua TROLL 400

Device SN = 734322

**Date Time**

6/3/21 13:06:00.000

**RDO Concentration (mg/L) (734143)**

Stream too shallow for sonde