

S.O.P. FOR RESETTING LEFT AND RIGHT SIDE MAIN BREAKERS

- 1. Push main breaker down to full open position.**
- 2. Turn off all Breakers on affected side. (Breaker handles down/open)**
- 3. Acknowledge all alarms on Main Computer Panel and on computer panel in office.**
- 4. Throw the Main breaker (close the switch).**
- 5. Turn on all affected breakers one at a time. (Close the breakers, handles up, switches to on if they have one.)**
- 6. Reset all alarms on Main Computer panel using master reset button on screen or master switch.**
- 7. Log the occurrence into the Plant notes and advise incoming operators of plant conditions**